


61.149.221.157 PD36R ACE说明书
105G铜板纸/单黑双面印刷/225*490mm/风琴折后56*98mm/A0

FENIX LIGHTING FOR EXTREMES
PD36R ACE
MULTI-MODE TACTICAL FLASHLIGHT
3000 LUMENS MAX OUTPUT
415 METERS MAX BEAM DISTANCE



TECHNICAL PARAMETERS table with columns: ANSIP/LATO FL1, TURBO, HIGH, MED, LOW, ECO, STROBE, SOS. Rows include Output, Runtime, Distance, Intensity, Impact Resistance, and Submersible.

Operating instructions and battery specifications. Includes sections for On/Off, Output Selection, SET mode adjustment, and a detailed BATTERY SPECIFICATIONS table with columns: Mode, Eco, Low, Med, High, Turbo, Strobe, SOS.

警告 (Warning)
(中文) FENIX PD36R ACE 说明书
操作说明
按说明
尾部分为战术正转开关、触即亮。
尾部分为战术正转开关、触即亮。
尾部分为战术正转开关、触即亮。

技术参数 (Technical Parameters) table with columns: ANSIP/LATO FL1, 亮度, 续航时间, 射程, 光强, 防护等级. Includes a section for 电池选项 (Battery Options) and 充电说明 (Charging Instructions).

LIGHTING FOR EXTREMES
FACEBOOK WECHAT
FENIXLIGHT LIMITED
Tel: +86-755-29631163/83/93 Fax: +86-755-29631181
E-mail: info@fenixlight.com Web: www.fenixlight.com

BATTERY LEVEL INDICATION
INTELLIGENT OVERHEAT PROTECTION
LOW-VOLTAGE WARNING
USAGE AND MAINTENANCE

WARNUNG
(DEUTSCH) TASCHENLAMPE FENIX PD36R ACE
BEDIENUNGSANLEITUNG
AVVERTENZE
(ITALIANO) TORCIA FENIX PD36R ACE

TECHNISCHE DATEN table with columns: ANSIP/LATO FL1, TURBO, HELL, MITTEL, DUNKEL, ECO, STROBE, SOS. Includes a section for TECHNISCHE DATEN DER AKKUS.

ANZEIGE DES AKKUSTANDS
INTELLIGENTER ÜBERLIEFERUNGSSCHUTZ
WARNUNG BEI ÜBERSCHÜSSIGKEIT
VERWENDUNG UND WARTUNG
LIEFERUMFANG

AVVERTENZE
(ITALIANO) TORCIA FENIX PD36R ACE
ISTRUZIONI OPERATIVE

PARAMETRI TECNICI table with columns: ANSIP/LATO FL1, TURBO, ALTO, MEDIO, BASSO, ECO, STROBO, SOS. Includes a section for SOSTITUZIONE DELLA BATTERIA.

INDICATORE DEL LIVELLO DELLA BATTERIA
PROTEZIONE INTELLIGENTE DAL SURRISCALDAMENTO
AVVISO DI BASSA TENSIONE
USO E MANUTENZIONE
INCLUSO NELLA CONFEZIONE

